

Immobiliser Function List			
Software Version: 26.31			
Automaker	Model/Protocol	System	Function
MITSUBISHI(China)	V73	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(China)	V97	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(China)	Galant	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(China)	Grandis	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(China)	Lancer(With smart)	Immobiliser	1. ECU identification 2. Live data<KEY_INFO> 3. Change security code 4. All smart keys lost 5. Program engine key code 6. Program engine key code&VIN write

MITSUBISHI(China)	Lancer(Without smart)	Immobiliser	1. ECU identification 2. Live data 3. Change security code 4. All keys lost 5. Program remote 6. Program engine key code 7. Program engine key code & VIN write
MITSUBISHI(China)	Outlander(-2013)	Immobiliser	1. ECU identification 2. Live data <KEY_INFO> 3. Change security code 4. All smart keys lost 5. Program engine key code 6. Program engine key code & VIN write
MITSUBISHI(China)	Outlander(2014-)	Immobiliser	Program smart keys
MITSUBISHI(China)	ASX	Immobiliser	Program smart keys
MITSUBISHI(China)	L200 TRITON(-2011)	Immobiliser(Type 1)	1. Program keys 2. Program remotes
MITSUBISHI(China)	L200 TRITON(-2011)	Immobiliser(Type 2)	1. All keys lost 2. Program remote
MITSUBISHI(China)	L200 TRITON(2011-)	Immobiliser(Type 1)	1. Program keys 2. Program remotes
MITSUBISHI(China)	L200 TRITON(2011-)	Immobiliser(Type 2)	1. All keys lost 2. Program remote
MITSUBISHI(China)	Pajero(-2010)	Immobiliser	1. Fault codes 2. Erase DTC 3. Live data 4. Program keys 5. Reset immobiliser
MITSUBISHI(China)	Pajero(2010-)	Immobiliser	1. Program keys 2. Program remotes
MITSUBISHI(China)	Pajero sport(-2011)	Immobiliser(Type 1)	1. Program keys 2. Program remotes
MITSUBISHI(China)	Pajero sport(-2011)	Immobiliser(Type 2)	1. All keys lost 2. Program remote
MITSUBISHI(China)	Pajero sport(2011-)	Immobiliser(Type 1)	1. Program keys 2. Program remotes

mitsubishi(China)	pajero sport(2011-)	Immobiliser(Type 2)	1.All keys lost 2.Program remote
mitsubishi(China)	Type 1(K)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
mitsubishi(China)	Type 2(CAN With smart)	Immobiliser	1. ECU identification 2. Live data<KEY_INFO> 3. Change security code 4. All smart keys lost 5. Program engine key code 6. Program engine key code&VIN write
mitsubishi(China)	Type 3(CAN With smart)	Immobiliser	Program smart keys
mitsubishi(China)	Type 4(CAN With smart)	Immobiliser	Program smart keys
mitsubishi(China)	Type 5(CAN Without smart)	Immobiliser	1. ECU identification 2. Live data 3. Change security code 4. All keys lost 5. Program remote 6. Program engine key code 7. Program engine key code&VIN write
mitsubishi(China)	Type 6(CAN Without smart)	Immobiliser	1. Program keys 2. Program remotes
mitsubishi(China)	Type 7(CAN Without smart)	Immobiliser	1. Change security code 2. All keys lost 3. Program remote 4. Program engine key code&VIN write
mitsubishi(China)	Type 8(CAN Without smart)	Immobiliser	1. All keys lost 2. Program remote
mitsubishi(japan)	Carisma(96-04)	Immobiliser	1. Fault codes 2. Erase DTC 3. Live data 4. Program keys 5. Reset immobiliser

MITSUBISHI(Japan)	Colt(96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Eclipse(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Galant[PIN1](96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Galant[PIN2](96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Lancer(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Lancer(03-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Lancer SW(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Japan)	L200(99-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 6.Reset immobiliser
MITSUBISHI(Japan)	Montero(99-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Montero(01-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Montero IO(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Montero Sport(99-04)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Nativa(01-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Pajero(96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Japan)	Pajero(00-05)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Pajero IO(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Pajero PININ(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Pajero Sport(99-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Shogun(96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Shogun(00-05)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Shogun PININ(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Japan)	Shogun Sport(99-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Space Gear(96-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Space Runner(98-99)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Space Runner(99-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Space Start[PIN1](99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Space Start[PIN2](99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	Space Wagon(98-98)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Japan)	Space Wagon(99-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Japan)	3000 GT(96-01)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Challenger(99-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Express(96-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Lancer(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Lancer(03-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Lancer SW(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Australia)	Magna(96-05)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Mirage(96-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Nimbus(98-99)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Nimbus(99-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Pajero(96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Pajero(00-05)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Pajero IO(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Australia)	Triton[PIN1](99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Triton[PIN2](99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Australia)	Verada(96-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Carisma(96-04)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Colt(96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Colt New(02-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Galant(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Greek)	Lancer(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Lancer SW(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	L200(99-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Pajero(96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Pajero New(00-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Pajero PININ(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Pajero Sport(99-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(Greek)	Space Gear(96-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Space Runner(98-99)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Space Runne(99-02)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	Space Start(99-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(Greek)	3000 GT(96-)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Diamante(00-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Eclipse(96-05)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Eclipse[CAN](06-09)	Immobiliser	1.All keys lost 2.Key N0.
MITSUBISHI(USA)	Endeavor[CAN](06-09)	Immobiliser	1.All keys lost 2.Key N0.

MITSUBISHI(USA)	Galant(04-05)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Galant[CAN](06-09)	Immobiliser	1.All keys lost 2.Key N0.
MITSUBISHI(USA)	Galant[PIN1](96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Galant[PIN1](00-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Galant[PIN2](96-00)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Galant[PIN2](00-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Lancer(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Lancer EVO(03-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser

MITSUBISHI(USA)	Lancer SW(96-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Lancer[CAN](08-09)	Immobiliser	1.All keys lost 2.Key N0.
MITSUBISHI(USA)	Montero(99-00)(01-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Montero Sport(99-04)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Outlander(00-03)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Outlander(04-06)	Immobiliser	1.Fault codes 2.Erase DTC 3.Live data 4.Program keys 5.Reset immobiliser
MITSUBISHI(USA)	Outlander[CAN](07-09)	Immobiliser	1.All keys lost 2.Key N0.