

Immobiliser Function List

Software Version: 26.21

Automaker	System	Type	Function
Honda/Acura	Immobiliser	Type 1(3 PIN)	1. System checking 2. Key Quantity 3. Key Types 4. Add a key 5. Erase keys 6. All keys lost
Honda/Acura	Immobiliser	Type 2(16 PIN)	1. System checking 2. Key Quantity 3. Key Types 4. Add a key 5. Erase keys 6. All keys lost 7. Replace immobiliser ECU 8. Replace the ECM / PCM 9. Replace MPCS / MICU / IMOES
Honda/Acura	Smart key system	Type 1(knob)	1. Add a smart key 2. Rewrite keys 3. All smart keys lost 4. Replace smart key ECU 5. Replace knob ignition
Honda/Acura	Smart key system	Type 2(button)	1. Add a smart key 2. All smart keys lost
Honda/Acura	Smart key system	Type 3(button)	1. Add a smart key 2. All smart keys lost
Honda/Acura	Remote	Type 1(9G)	1. Add remotes 2. Erase remotes
Honda/Acura	Remote	Type 2	1. Program remote 2. Remote identification