

Nissan/Infiniti program keys function list

Software Version: 26.50

Automaker	Area	Model/Ecu	Year	Function
Nissan/Infiniti	All	Pin Calculator		Calculate Pin code by BCM CODE(5 bit)
Nissan/Infiniti	All	Pin Calculator		Calculate Pin code by The label
Nissan/Infiniti	China	Immobiliser system - type 1		1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	China	Immobiliser system - type 2		1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	China	Immobiliser system - type 3		1. Erase DTC 2. Program keys
Nissan/Infiniti	China	Immobiliser system - type 4		1.Number of keys 2.Program keys
Nissan/Infiniti	China	Immobiliser system - type 5		1.Number of keys 2.Program keys
Nissan/Infiniti	China	Smart key system - type 1		1.Program smart keys 2.Erase all smart keys 3.Program steering lock
Nissan/Infiniti	China	Smart key system - type 2		1. Erase DTC 2. Program smart keys
Nissan/Infiniti	China	Smart key system - type 3		1.Read BCM code 2.Release steering lock 3.Program smart keys

Nissan/Infiniti	China	Smart key system - type 4		1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	China	Smart key system - type 5		1. Program smart keys 2. Erase all smart keys
Nissan/Infiniti	China	Smart key system - type 6		1.Program smart keys 2.Replace engine ECU
Nissan/Infiniti	China	Smart key system - type 7		1.Program smart keys
Nissan/Infiniti	China	Smart key system - type 8		1.Read number of keys 2.Program keys 3.Program remote 4.Erase remotes
Nissan/Infiniti	China	Body System(BCM) - type 1		1. Read BCM code 2. Release steering lock
Nissan/Infiniti	China	Body System(BCM) - type 2		1. Read BCM code 2. Release steering lock
Nissan/Infiniti	China	Remote		1. Read BCM code 2. Release steering lock
Nissan/Infiniti		Teana(Body System(BCM)(BCM))	2009-2011	1. Read BCM code 2. Release steering lock
Nissan/Infiniti		Teana(Smart key system)	2009-2011	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti		Teana(BCM)	2012	1. Read BCM code 2. Release steering lock
Nissan/Infiniti		Teana(Smart key system)	2012	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti		Teana(Smart key system)	2013-	1.Program smart keys 2.Replace engine ECU

Nissan/Infiniti		New March(Smart key system)		1.Read BCM code 2.Release steering lock 3.Program smart keys
Nissan/Infiniti		New Sunny(Smart key system)		1.Read BCM code 2.Release steering lock 3.Program smart keys
Nissan/Infiniti		New Tiida(Smart key system)		1.Read BCM code 2.Release steering lock 3.Program smart keys
Nissan/Infiniti		Qichen(Body System(BCM)(BCM))		1. Read BCM code 2. Release steering lock
Nissan/Infiniti		Qichen(Immobiliser system)		1.Erase DTC 2.Program smart keys
Nissan/Infiniti		X-Trail(Smart key system)	2013-	Program smart keys
Nissan/Infiniti		JX35(Smart key system)	2013-	1.Program smart keys 2.Replace engine ECU
Nissan/Infiniti		QX60(Smart key system)	2013-	1.Program smart keys 2.Replace engine ECU
Nissan/Infiniti		Murano		Program smart keys
Nissan/Infiniti	USA	Altima	2000-2006	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Altima Cp[PRX]	2007-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Altima Se[PRX]	2007-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Armada[NATS 5]	2004-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Armada[IK]	2008-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Armada[NT5]	2008-2010	1. Erase DTC 2. Program keys

Nissan/Infiniti	USA	Frontier[NATS 5]	2006-2010	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Livina[NT5]	2007-2008	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Livina[PRX]	2007-2008	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Maxima[NATS 5]	1999-2006	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Maxima[iK]	2008-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Murano[NATS 5]	2003-2008	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Murano[iK]	2005-2008	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Murano[PRX]	2009-2009	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Pathfinder[NATS 5]	1999-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Pathfinder[iK]	2008-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Pathfinder[NT5]	2008-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Quest[NATS 5]	2004-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Quest[NT5]	2008-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Rogue[iK]	2007-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Rogue[NT5]	2007-2010	1. Erase DTC 2. Program keys

Nissan/Infiniti	USA	Sentra[NATS 5]	2000-2006	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Sentra[iK]	2007-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Sentra[NT5]	2007-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Tiida[NT5]	2007-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Titna[NATS 5]	2004-2008	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Titna[NT5]	2008-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Versa[iK]	2007-2010	1.Read BCM code 2.Program keys
Nissan/Infiniti	USA	Versa[NT5]	2007-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	Xterra[NATS 5]	2003-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	Xterra[NT5]	2008-2010	1. Erase DTC 2. Program keys
Nissan/Infiniti	USA	350-Z[NATS 5]	2004-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	350-Z Roadster[NATS 5]	2004-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	USA	350-Z[iGN]	2008-2008	1. Erase DTC 2. Program keys
Nissan/Infiniti	Japan	Cefrio[NATS 5]	2000-2003	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Japan	Infiniti[NATS 5]	1997-1999	1. Fault codes 2. Erase DTC 3. Program keys

Nissan/Infiniti	Japan	Laurel[NATS 5]	1999-2002	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Japan	Micra march[NATS 5]	1996-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Japan	Sunny[NATS 5]	1996-1998	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Japan	X-trail[NATS 5]	1998-2005	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Trucks	Atleon[NATS 5]	2002-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Trucks	Cab star	2000-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Almera[NATS 5]	1999-2003	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Almera tino[NATS 5]	2000-2003	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Altima[NATS 5]	2000-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Infiniti	2005-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Interstar	2002-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Maxima[NATS 5]	1995-2003	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Micra[NATS 5]	1996-2004	1. Fault codes 2. Erase DTC 3. Program keys

Nissan/Infiniti	Other	Micra van[NATS 5]	2000-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Nx almera[NATS 5]	1995-2000	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Pathfinder[NATS 5]	1999-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Patrol[NATS 5]	1998-2003	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Primera[NATS 5]	1995-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Pulsar[NATS 5]	1995-2004	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Sentra[NATS 5]	2001-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Terrano II[NATS 5]	1995-2001	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	Xterra[NATS 5]	2000-2004	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	X-trail[NATS 5]	1998-2005	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	Other	350-Z[NATS 5]	2003-	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	Fx35[NATS 5]	2003-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	Fx45[NATS 5]	2003-2007	1. Fault codes 2. Erase DTC 3. Program keys

Nissan/Infiniti	ALL	G20[NATS 5]	2000-2002	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	G35[NATS 5]	2003-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	I30[NATS 5]	1999-2004	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	M35[NATS 5]	2003-2006	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	M45[NATS 5]	2003-2007	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	Qx4[NATS 5]	1999-2003	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	Qx56[NATS 5]	2004-2006	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti	ALL	Q45[NATS 5]	1997-2006	1. Fault codes 2. Erase DTC 3. Program keys
Nissan/Infiniti		Remote(type 1)		1.Program a remote key 2.Erase remote keys
Nissan/Infiniti		Remote(type 2)		1.Program remote 2.Erase remotes