

Immobiliser Function List

Software Version: 26.03

Automaker	Model/Protocol	System	Function
OPEL		Read security code	1.Switch ignition on 2.Read security code
OPEL	Type 1	Immobiliser	1.With smart (1)Program smart keys (2)Clear DTC (3)Read data stream 2.Without smart (1)Program smart keys (2)Clear DTC (3)Read data stream
OPEL	Type 2	Immobiliser	1ECU identification 2Fault codes 3Erase DTC 4Live data 5Input security code (1)Input security code 6Program function (1)Program keys (2)Erase keys
OPEL	Type 1	Remote	1.Erase remote keys 2.Program remote key
OPEL	Type 2	Remote	1.Erase remote keys 2.Program remote key