

## Immobiliser Function List

**Software Version: 26.02**

Automaker	Model/Protocol	System	Function
LUFENG	TYPE 1	Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Set security code 6.Program function
LUFENG	TYPE 2	Immobiliser	1.ECU identification 2.Read DTC 3.Clear DTC 4.Read data stream 5.Set security code 6.Program function