

## Immobiliser Function List

**Software Version: 26.11**

Automaker	Model	System	Function
BESTURN	Old besturn(CAN)	Immobiliser	<ol style="list-style-type: none"> <li>1. Number of keys</li> <li>2. Add a key</li> <li>3. All keys lost</li> </ol>
BESTURN	B50	Immobiliser	<ol style="list-style-type: none"> <li>1. ECU identification</li> <li>2. Fault codes</li> <li>3. Erase DTC</li> <li>4. Live data</li> <li>5. Erase keys</li> <li>6. Program keys</li> </ol>
BESTURN	B70	Immobiliser	<ol style="list-style-type: none"> <li>1. ECU identification</li> <li>2. Fault codes</li> <li>3. Erase DTC</li> <li>4. Live data</li> <li>5. Erase keys</li> <li>6. Program keys</li> </ol>
BESTURN	X80	Immobiliser	<ol style="list-style-type: none"> <li>1. ECU identification</li> <li>2. Fault codes</li> <li>3. Erase DTC</li> <li>4. Live data</li> <li>5. Erase keys</li> <li>6. Program keys</li> </ol>

BESTURN	B90	Immobiliser	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Erase keys 6. Program keys
BESTURN	Oley	Immobiliser	1. ECU identification 2. Fault codes 3. Erase DTC 4. Live data 5. Erase keys 6. Program keys