

Immobiliser Function List

Software Version: 26.11

Automaker	Model	System	Function
BYD	Su rui	Smart key	1. Program related smart key 2. Program new smart keys
BYD	Si rui	Smart key	1. Program related smart key 2. Program new smart keys
BYD	Qin	Smart key	1. Program related smart key 2. Program new smart keys
BYD	S7	Smart key	1. Program related smart key 2. Program new smart keys
BYD	G5	Smart key	1. Program related smart key 2. Program new smart keys
BYD	G6	Smart key	1. Program related smart key 2. Program new smart keys
BYD	L3	Smart key	1. Program related smart key 2. Program new smart keys
BYD	F3	Smart key	1. Program related smart key 2. Program new smart keys
BYD	S6	Smart key	1. Program related smart key 2. Program new smart keys
BYD	VA	Smart key	1. Program related smart key 2. Program new smart keys
BYD	E6A	Smart key	1. Program related smart key 2. Program new smart keys
BYD	E6B	Smart key	1. Program related smart key 2. Program new smart keys
BYD	E6Y	Smart key	1. Program related smart key 2. Program new smart keys
BYD	F0	Smart key	1. Program related smart key 2. Program new smart keys
BYD	G3	Smart key	1. Program related smart key 2. Program new smart keys

BYD	M6	Smart key	1. Program related smart key 2. Program new smart keys
BYD	F3R	Smart key	1. Program related smart key 2. Program new smart keys