

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Audi	4B0959655B	Memory Directly	OBP	Airbag ECU
Audi	4B0959655G	Soldering Contacts	K&CAN	Airbag ECU
Audi	4B0959655J	Soldering Contacts	K&CAN	Airbag ECU
Audi	8A0959655B	Soldering Contacts	K&CAN	Airbag ECU
Chrysler	TMD310737636-0285001093	Soldering Contacts	ICP	Airbag ECU
Chrysler	TNDME0518D7119	Memory Directly	OBP	Airbag ECU
Chrysler	TMD074830084	Memory Directly	OBP	Airbag ECU
Chrysler	TNDME3417D7123	Memory Directly	OBP	Airbag ECU
Citroen	0116390Q	Memory Directly	OBP	Airbag ECU
Citroen	0150871h	Memory Directly	OBP	Airbag ECU
Citroen	0160443D	Memory Directly	OBP	Airbag ECU
Citroen	0211549P	Memory Directly	OBP	Airbag ECU
Citroen	550519300	Memory Directly	OBP	Airbag ECU
Citroen	550776300	Memory Directly	OBP	Airbag ECU
Citroen	550893100	Memory Directly	OBP	Airbag ECU
Citroen	5WK44153	Memory Directly	OBP	Airbag ECU
Citroen	600237600	Memory Directly	OBP	Airbag ECU
Citroen	601951800	Memory Directly	OBP	Airbag ECU
Citroen	602327400	Memory Directly	OBP	Airbag ECU
Citroen	610798500	Memory Directly	OBP	Airbag ECU
Citroen	9622585880	Memory Directly	OBP	Airbag ECU
Citroen	9633621380	Memory Directly	OBP	Airbag ECU
Citroen	9637176880	Memory Directly	OBP	Airbag ECU
Citroen	9652276980	Memory Directly	OBP	Airbag ECU
Citroen	9658177080	Memory Directly	OBP	Airbag ECU
Citroen	9659111980	Memory Directly	OBP	Airbag ECU
Citroen	9661872980	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Citroen	9662643980	Memory Directly	OBP	Airbag ECU
Citroen	J3858079	Memory Directly	OBP	Airbag ECU
Citroen	J3858078	Memory Directly	OBP	Airbag ECU
Citroen	ZQ00731180	Memory Directly	OBP	Airbag ECU
Citroen	ZQ00731280	Memory Directly	OBP	Airbag ECU
Citroen	ZQ00811280	Memory Directly	OBP	Airbag ECU
Citroen	9804870280	Memory Directly	OBP	Airbag ECU
Citroen	9804502280	Memory Directly	OBP	Airbag ECU
Citroen	9805062680	Memory Directly	OBP	Airbag ECU
FIAT	46758762	Memory Directly	OBP	Airbag ECU
FIAT	46765164	Memory Directly	OBP	Airbag ECU
FIAT	46765165	Memory Directly	OBP	Airbag ECU
FIAT	51718980	Memory Directly	OBP	Airbag ECU
FIAT	51718981	Memory Directly	OBP	Airbag ECU
Ford	1S7T14B056	Memory Directly	OBP	Airbag ECU
Ford	28556-6B200	Soldering Contacts	ICP	Airbag ECU
Ford	3S7T-14B056	Memory Directly	OBP	Airbag ECU
Ford	4M5T14B056BJ	Memory Directly	OBP	Airbag ECU
Ford	4M5T14B056CA	Memory Directly	OBP	Airbag ECU
Ford	4S7T-14B056	Memory Directly	OBP	Airbag ECU
Ford	4S7T-14B056-AB	Memory Directly	OBP	Airbag ECU
Ford	4S7T-14B056-AC	Memory Directly	OBP	Airbag ECU
Ford	7S7T-14B056	Memory Directly	OBP	Airbag ECU
Ford	7S7T-14B56-BC	Memory Directly	OBP	Airbag ECU
Ford	4S7T-14B056-AD	Memory Directly	OBP	Airbag ECU
Ford	8M5T-14B321BD	Memory Directly	OBP	Airbag ECU
Ford	8M5T-14B321BF	Memory Directly	OBP	Airbag ECU

**DigiMasterIII-Airbag resetting Car Model List**

Manufacturer	Airbag ECU Type		Method	Adapter	Storage Location
Ford	8V59-14B321		Memory Directly	OBP	Airbag ECU
Ford	9M5T14B321BA		Memory Directly	OBP	Airbag ECU
Ford	YS6T14B056AD		Soldering Contacts	ICP	Airbag ECU
Ford	6M64-14B321-GB		Memory Directly	OBP	Airbag ECU
Ford	9M5T-14B321-BB		Memory Directly	OBP	Airbag ECU
GM	Aveo	5WK43688	Memory Directly	OBP	Airbag ECU
GM	Aveo	9033235	Memory Directly	OBP	Airbag ECU
GM	Aveo	9039025	Memory Directly	OBP	Airbag ECU
GM	Buick V1		Soldering Contacts	ICP	Airbag ECU
GM	Buick V2		Soldering Contacts	ICP	Airbag ECU
GM	E530UKM110		Memory Directly	OBP	Airbag ECU
GM	Epica	5WY64038	Memory Directly	OBP	Airbag ECU
GM	Epica	5WY67098	Memory Directly	OBP	Airbag ECU
GM	Epica	9012527	Memory Directly	OBP	Airbag ECU
GM	Epica	9018740	Memory Directly	OBP	Airbag ECU
GM	Epica	SGM_811_9046171	Soldering Contacts	ICP	Airbag ECU
GM	Excele	5wk43878	Memory Directly	OBP	Airbag ECU
GM	Excele	9012526	Memory Directly	OBP	Airbag ECU
GM	Excele	9012527	Memory Directly	OBP	Airbag ECU
GM	Excele	9042475	Memory Directly	OBP	Airbag ECU
GM	Excele	5W43710 V1	Memory Directly	OBP	Airbag ECU
GM	Excele	5W43710 V2	Memory Directly	OBP	Airbag ECU
GM	Excele	96406712	Memory Directly	OBP	Airbag ECU
GM	Excele	96818875	Memory Directly	OBP	Airbag ECU
GM	Imported Deville		Soldering Contacts	ICP	Airbag ECU
GM	LaCROSSE		Soldering Contacts	ICP	Airbag ECU
GM	Lova	09036078	Soldering Contacts	ICP	Airbag ECU

Manufacturer	Airbag ECU Type		Method	Adapter	Storage Location
GM	Lova	9012528	Memory Directly	OBP	Airbag ECU
GM	Lova	9070418	Memory Directly	OBP	Airbag ECU
GM	Lova	SDM 9024354	Memory Directly	OBP	Airbag ECU
GM	Lova	SGMT250- 9029659	Memory Directly	OBP	Airbag ECU
GM	Sail	05490636	Soldering Contacts	K&CAN	Airbag ECU
GM	Sail	05498640	Memory Directly	OBP	Airbag ECU
GM	Sail	9012494	Memory Directly	OBP	Airbag ECU
GM	Sail	9024821	Memory Directly	OBP	Airbag ECU
GM	Sail	92099726	Soldering Contacts	K&CAN	Airbag ECU
GM	sail	CPU	Soldering Contacts	ICP	Airbag ECU
GM	SGM400 SDM 5492510		Soldering Contacts	ICP	Airbag ECU
GM	Spark	J3858110 5WK44246	Memory Directly	OBP	Airbag ECU
GM	Spark	96644507	Memory Directly	OBP	Airbag ECU
GM	Spark	J3858020 5WK43688	Memory Directly	OBP	Airbag ECU
GM	96866798(Captiva)		Memory Directly	OBP	Airbag ECU
GM	10366054(H2)		Memory Directly	OBP	Airbag ECU
GM	Impala	25927274	Memory Directly	OBP	Airbag ECU
Honda	Accord 2.2 CD5		Memory Directly	OBP	Airbag ECU
Honda	Accord 2.3 S84-A86		Memory Directly	OBP	Airbag ECU
Honda	Accord 2002 2.4		Memory Directly	OBP	Airbag ECU
Honda	City		Soldering Contacts	K&CAN	Airbag ECU
Honda	CRV		Memory Directly	OBP	Airbag ECU
Honda	FIT		Soldering Contacts	K&CAN	Airbag ECU
Honda	77960-S03-G81-M2		Memory Directly	OBP	Airbag ECU
Honda	77960-S04-G81-M2		Memory Directly	OBP	Airbag ECU
Honda	77960-S04-N91-M2		Memory Directly	OBP	Airbag ECU
Honda	77960-S04-N93-M2		Memory Directly	OBP	Airbag ECU

Manufacturer	Airbag ECU Type	Method	Adapter	Storage Location
Honda	77960-S10-G92	Memory Directly	OBP	Airbag ECU
Honda	77960-S2H-G010-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-S30-G81-M2	Memory Directly	OBP	Airbag ECU
Honda	77960-S3N-N93 V1	Memory Directly	OBP	Airbag ECU
Honda	77960-S3N-N93 V2	Memory Directly	OBP	Airbag ECU
Honda	77960-S4N-G010-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-S4N-G020-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-S84-A81	Memory Directly	OBP	Airbag ECU
Honda	77960-S84-A832-C1	Soldering Contacts	ICP	Airbag ECU
Honda	77960-S84-A84 V1	Memory Directly	OBP	Airbag ECU
Honda	77960-S84-A84 V2	Memory Directly	OBP	Airbag ECU
Honda	77960-S84-A86 V1	Memory Directly	OBP	Airbag ECU
Honda	77960-S84-A86 V2	Memory Directly	OBP	Airbag ECU
Honda	77960-S9A-N810-M2	Memory Directly	OBP	Airbag ECU
Honda	77960-S9A-Y412-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-S9A-Y413-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-S9A-Y414-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-A815-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-C024-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-C211-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-L914-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y613-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y614-M1 V1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y614-M1 V2	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y615-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y630-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y631	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Honda	77960-SDA-Y840	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y914-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SDA-Y915	Memory Directly	OBP	Airbag ECU
Honda	77960-SEP-A111-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SFJ-W710-M2	Memory Directly	OBP	Airbag ECU
Honda	77960-SFJ-W910-M2	Memory Directly	OBP	Airbag ECU
Honda	77960-SHJ-A020-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SHJ-C012-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SLE-H012-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-SLE-H812-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-SLN-L230-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-A218-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-A220-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-A230-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H010-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H020-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H222-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H811-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H821-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H822-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-H830-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-L211-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SV4-308	Memory Directly	OBP	Airbag ECU
Honda	77960-SV4-A91	Memory Directly	OBP	Airbag ECU
Honda	77960-SV4-A92	Memory Directly	OBP	Airbag ECU
Honda	77960-SV4-A93	Memory Directly	OBP	Airbag ECU
Honda	77960-SV4-A94	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Honda	77960-SV4-A95	Memory Directly	OBP	Airbag ECU
Honda	77960-SVA-A221-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SWA-H010-M4	Memory Directly	OBP	Airbag ECU
Honda	77960-SWA-H812-M4	Memory Directly	OBP	Airbag ECU
Honda	77960-SX0-A82	Memory Directly	OBP	Airbag ECU
Honda	77960-SX0-A84 V1	Memory Directly	OBP	Airbag ECU
Honda	77960-SX0-A84 V2	Memory Directly	OBP	Airbag ECU
Honda	77960-SX0-G81-M2	Memory Directly	OBP	Airbag ECU
Honda	77960-SZ3-G810-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TA0-A011-M4	Memory Directly	OBP	Airbag ECU
Honda	77960-TCO-H011-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TCO-H012-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TCO-H212-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TF0-H620-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TF0-H621-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TF0-H820-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TFO-H420-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TFO-H421-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TK4-A011-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TK4-H012-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TM0-H421-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TM0-X621-M3	Memory Directly	OBP	Airbag ECU
Honda	77960-TP5-H111-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SWA-H213-M4	Memory Directly	OBP	Airbag ECU
Honda	77960-SOK-A82-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNA-A219-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SEP-H212-M1	Memory Directly	OBP	Airbag ECU

Manufacturer	Airbag ECU Type	Method	Adapter	Storage Location
Honda	77960-SDA-C014-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SVA-A211-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TR0-H714-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-S84-A72	Memory Directly	OBP	Airbag ECU
Honda	77960-TR0-H715-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-SNW-J611-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-TR0-A013-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-T0A-H912-M4	Memory Directly	OBP	Airbag ECU
Honda	77960-T0A-H911-M4	Memory Directly	OBP	Airbag ECU
Honda	77960-S0L-H410-M2	Memory Directly	OBP	Airbag ECU
Honda	77960-TR0-H720-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-T2A-H911-M1	Memory Directly	OBP	Airbag ECU
Honda	77960-T6P-H611-M1	Memory Directly	OBP	Airbag ECU
Hyundai	95910-08000	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-09100	Memory Directly	OBP	Airbag ECU
Hyundai	95910-0L100	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-0M000	Memory Directly	OBP	Airbag ECU
Hyundai	95910-0Q000	Memory Directly	OBP	Airbag ECU
Hyundai	95910-0U100	Memory Directly	OBP	Airbag ECU
Hyundai	95910-17150	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-1E000	Memory Directly	OBP	Airbag ECU
Hyundai	95910-1E100	Memory Directly	OBP	Airbag ECU
Hyundai	95910-1F000	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-26100	Memory Directly	OBP	Airbag ECU
Hyundai	95910-26200	Memory Directly	OBP	Airbag ECU
Hyundai	95910-26600	Memory Directly	OBP	Airbag ECU
Hyundai	95960-27100	Soldering Contacts	ICP	Airbag ECU



<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Hyundai	95960-29000	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2B080	Memory Directly	OBP	Airbag ECU
Hyundai	95910-2B270	Memory Directly	OBP	Airbag ECU
Hyundai	95910-2C200	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2C500	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2D700	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2D710	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2D720	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2E200	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2E300	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-2E400	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-34220	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-34510	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-37910	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-39900	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3A100	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-3B470	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3D000	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3D100	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3D200	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3K300	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3K400	Memory Directly	OBP	Airbag ECU
Hyundai	95910-H1200	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-H1300	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-H1400	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-H1500	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-H1700	Soldering Contacts	ICP	Airbag ECU

Manufacturer	Airbag ECU Type	Method	Adapter	Storage Location
Hyundai	95910-0Q500	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-0R200	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3B460	Memory Directly	OBP	Airbag ECU
Hyundai	95910-2Z200	Memory Directly	OBP	Airbag ECU
Hyundai	95910-0L200	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-08400	Soldering Contacts	ICP	Airbag ECU
Hyundai	95910-4V100	Memory Directly	OBP	Airbag ECU
Hyundai	95910-2Z700	Memory Directly	OBP	Airbag ECU
Hyundai	95910-3Q110	Memory Directly	OBP	Airbag ECU
Hyundai	95910-2Z000	Memory Directly	OBP	Airbag ECU
Hyundai	95910-2V200	Memory Directly	OBP	Airbag ECU
KIA	95910-03100	Soldering Contacts	ICP	Airbag ECU
KIA	95910-0C100	Memory Directly	OBP	Airbag ECU
KIA	95910-0C300	Memory Directly	OBP	Airbag ECU
KIA	95910-0S600	Memory Directly	OBP	Airbag ECU
KIA	95910-1D400	Memory Directly	OBP	Airbag ECU
KIA	95910-1G000	Memory Directly	OBP	Airbag ECU
KIA	95910-22400	Soldering Contacts	ICP	Airbag ECU
KIA	95910-22410	Soldering Contacts	ICP	Airbag ECU
KIA	95910-2F100	Memory Directly	OBP	Airbag ECU
KIA	95910-2F200	Memory Directly	OBP	Airbag ECU
KIA	95910-3C100	Soldering Contacts	ICP	Airbag ECU
KIA	95910-3C200	Soldering Contacts	ICP	Airbag ECU
KIA	95910-3F000	Memory Directly	OBP	Airbag ECU
KIA	95910-3F300	Memory Directly	OBP	Airbag ECU
KIA	95910-3C000	Soldering Contacts	ICP	Airbag ECU
KIA	95910-2J500	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
KIA	J50K2FE	Memory Directly	OBP	Airbag ECU
KIA	95910-0S500	Memory Directly	OBP	Airbag ECU
KIA	95910-1X000	Memory Directly	OBP	Airbag ECU
KIA	J50K2FE67-7F0	Memory Directly	OBP	Airbag ECU
KIA	Kia Carnival	Soldering Contacts	ICP	Airbag ECU
KIA	95910-0C400	Memory Directly	OBP	Airbag ECU
KIA	95910-4X000	Memory Directly	OBP	Airbag ECU
KIA	95910-0Q500	Soldering Contacts	ICP	Airbag ECU
KIA	95910-3F850	Memory Directly	OBP	Airbag ECU
Land Rover	6H5214B321AE	Memory Directly	OBP	Airbag ECU
Land Rover	9H5214D374AC	Memory Directly	OBP	Airbag ECU
Land Rover	YWC000610	Memory Directly	OBP	Airbag ECU
Land Rover	AH4214D374AF	Memory Directly	OBP	Airbag ECU
Mazda	B30E57K30B	Memory Directly	OBP	Airbag ECU
Mazda	BR5 S57 K30 C	Memory Directly	OBP	Airbag ECU
Mazda	BR9N57K30	Memory Directly	OBP	Airbag ECU
Mazda	C10057K30A	Memory Directly	OBP	Airbag ECU
Mazda	C17657K30B	Memory Directly	OBP	Airbag ECU
Mazda	CC437724051	Memory Directly	OBP	Airbag ECU
Mazda	FA03-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	FA11-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	FA11-57-K30M2	Memory Directly	OBP	Airbag ECU
Mazda	FA13-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	G31A57K30B	Memory Directly	OBP	Airbag ECU
Mazda	G31F57K30A	Memory Directly	OBP	Airbag ECU
Mazda	GJ6A57K30C	Memory Directly	OBP	Airbag ECU
Mazda	GJ6R57K30D	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Mazda	GS1D-57K30	Memory Directly	OBP	Airbag ECU
Mazda	HA00-57-K30 M1	Soldering Contacts	ICP	Airbag ECU
Mazda	HMCA-57-K30	Memory Directly	OBP	Airbag ECU
Mazda	HMFA-57-K30	Memory Directly	OBP	Airbag ECU
Mazda	MA20-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	MA30-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	SA00-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	4A02-E10-0000-0	Memory Directly	OBP	Airbag ECU
Mazda	G33D-57K30	Memory Directly	OBP	Airbag ECU
Mazda	4A01-E10-0000-0	Memory Directly	OBP	Airbag ECU
Mazda	PA10-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	MA40-57-K30M1	Memory Directly	OBP	Airbag ECU
Mazda	MA10-57-K30MA	Memory Directly	OBP	Airbag ECU
Mazda	BFB657K30	Memory Directly	OBP	Airbag ECU
Mitsubishi	MB942715	Memory Directly	OBP	Airbag ECU
Mitsubishi	MB953174	Memory Directly	OBP	Airbag ECU
Mitsubishi	MB953175	Memory Directly	OBP	Airbag ECU
Mitsubishi	MN141399	Memory Directly	OBP	Airbag ECU
Mitsubishi	MN141499	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR268154	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR268156D	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR268157	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR329120	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR472776	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR551775	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR551800	Memory Directly	OBP	Airbag ECU
Mitsubishi	MR587804	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Mitsubishi	MR942715	Memory Directly	OBP	Airbag ECU
Mitsubishi	W2T6497	Memory Directly	OBP	Airbag ECU
Mitsubishi	8635A154 W2T65373	Memory Directly	OBP	Airbag ECU
Mitsubishi	P8635A247	Memory Directly	OBP	Airbag ECU
Mitsubishi	P8635A207	Memory Directly	OBP	Airbag ECU
Nissan	1L270(A32)	Memory Directly	OBP	Airbag ECU
Nissan	285561HD0A	Memory Directly	OBP	Airbag ECU
Nissan	285562L700	Memory Directly	OBP	Airbag ECU
Nissan	285562S700	Memory Directly	OBP	Airbag ECU
Nissan	285563AD0A	Memory Directly	OBP	Airbag ECU
Nissan	285563N705	Memory Directly	OBP	Airbag ECU
Nissan	2855641U00	Memory Directly	OBP	Airbag ECU
Nissan	2855643U00	Memory Directly	OBP	Airbag ECU
Nissan	2855653U00	Memory Directly	OBP	Airbag ECU
Nissan	285565E900(V1)	Memory Directly	OBP	Airbag ECU
Nissan	285565E900(V2)	Memory Directly	OBP	Airbag ECU
Nissan	285565E905	Memory Directly	OBP	Airbag ECU
Nissan	285565E910	Memory Directly	OBP	Airbag ECU
Nissan	285565E911	Memory Directly	OBP	Airbag ECU
Nissan	285565N312	Memory Directly	OBP	Airbag ECU
Nissan	285565P9500	Memory Directly	OBP	Airbag ECU
Nissan	285567M605	Memory Directly	OBP	Airbag ECU
Nissan	285567M60E	Memory Directly	OBP	Airbag ECU
Nissan	285567M62E	Memory Directly	OBP	Airbag ECU
Nissan	285567M806	Memory Directly	OBP	Airbag ECU
Nissan	285568H505	Memory Directly	OBP	Airbag ECU
Nissan	285569S600	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Nissan	285569S60A	Memory Directly	OBP	Airbag ECU
Nissan	285569W100	Memory Directly	OBP	Airbag ECU
Nissan	285569W10E	Memory Directly	OBP	Airbag ECU
Nissan	285569W13E	Memory Directly	OBP	Airbag ECU
Nissan	28556CJ00A	Memory Directly	OBP	Airbag ECU
Nissan	28556CJ00C	Memory Directly	OBP	Airbag ECU
Nissan	28556CJ00D	Memory Directly	OBP	Airbag ECU
Nissan	28556ED500	Memory Directly	OBP	Airbag ECU
Nissan	28556EU10A	Memory Directly	OBP	Airbag ECU
Nissan	28556EW300	Memory Directly	OBP	Airbag ECU
Nissan	28556EW32C	Memory Directly	OBP	Airbag ECU
Nissan	28556EW32D	Memory Directly	OBP	Airbag ECU
Nissan	28556EW32E	Memory Directly	OBP	Airbag ECU
Nissan	28556JX01B	Memory Directly	OBP	Airbag ECU
Nissan	28556JE20A	Memory Directly	OBP	Airbag ECU
Nissan	28556VJ301	Memory Directly	OBP	Airbag ECU
Nissan	28556VK000	Memory Directly	OBP	Airbag ECU
Nissan	28556VK00A	Memory Directly	OBP	Airbag ECU
Nissan	28556VK100	Memory Directly	OBP	Airbag ECU
Nissan	28556WL000	Memory Directly	OBP	Airbag ECU
Nissan	8820CL72B	Memory Directly	OBP	Airbag ECU
Nissan	988201BM0A	Memory Directly	OBP	Airbag ECU
Nissan	988201CM0A	Memory Directly	OBP	Airbag ECU
Nissan	988201NC0A	Memory Directly	OBP	Airbag ECU
Nissan	988201ND0A	Memory Directly	OBP	Airbag ECU
Nissan	988201WW0A	Memory Directly	OBP	Airbag ECU
Nissan	988202Y100	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Nissan	988203DF0A	Memory Directly	OBP	Airbag ECU
Nissan	988203L306	Memory Directly	OBP	Airbag ECU
Nissan	988203L400	Memory Directly	OBP	Airbag ECU
Nissan	988203L405	Memory Directly	OBP	Airbag ECU
Nissan	988204W305	Memory Directly	OBP	Airbag ECU
Nissan	988204W615	Memory Directly	OBP	Airbag ECU
Nissan	988204Y715	Memory Directly	OBP	Airbag ECU
Nissan	988205Y607	Memory Directly	OBP	Airbag ECU
Nissan	988205Z101	Memory Directly	OBP	Airbag ECU
Nissan	988207M715	Memory Directly	OBP	Airbag ECU
Nissan	988207M805	Memory Directly	OBP	Airbag ECU
Nissan	988207Y101	Memory Directly	OBP	Airbag ECU
Nissan	988208H405	Memory Directly	OBP	Airbag ECU
Nissan	988208H40E	Memory Directly	OBP	Airbag ECU
Nissan	988208H43E	Memory Directly	OBP	Airbag ECU
Nissan	988208Y70A	Memory Directly	OBP	Airbag ECU
Nissan	988209H605	Memory Directly	OBP	Airbag ECU
Nissan	988209M000	Memory Directly	OBP	Airbag ECU
Nissan	988209Y600	Memory Directly	OBP	Airbag ECU
Nissan	988209Y63E	Memory Directly	OBP	Airbag ECU
Nissan	98820A100	Memory Directly	OBP	Airbag ECU
Nissan	98820CG700	Memory Directly	OBP	Airbag ECU
Nissan	98820EH500	Memory Directly	OBP	Airbag ECU
Nissan	98820EJ30A	Memory Directly	OBP	Airbag ECU
Nissan	98820EM30B	Memory Directly	OBP	Airbag ECU
Nissan	98820EX70A	Memory Directly	OBP	Airbag ECU
Nissan	98820EX70B	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Nissan	98820JE30A	Memory Directly	OBP	Airbag ECU
Nissan	98820JE50A	Memory Directly	OBP	Airbag ECU
Nissan	98820JK600	Memory Directly	OBP	Airbag ECU
Nissan	98820JM100	Memory Directly	OBP	Airbag ECU
Nissan	98820JN30A	Memory Directly	OBP	Airbag ECU
Nissan	98820ZX60A	Memory Directly	OBP	Airbag ECU
Nissan	98820JL20A	Memory Directly	OBP	Airbag ECU
Nissan	98820JN30B	Memory Directly	OBP	Airbag ECU
Nissan	28556JX03B	Memory Directly	OBP	Airbag ECU
Nissan	28556JC20B	Memory Directly	OBP	Airbag ECU
Nissan	988201DF0B	Memory Directly	OBP	Airbag ECU
Nissan	28556W6600	Memory Directly	OBP	Airbag ECU
Nissan	988203ZB0A	Memory Directly	OBP	Airbag ECU
Nissan	285563DE0A	Memory Directly	OBP	Airbag ECU
Nissan	285563UZ0A	Memory Directly	OBP	Airbag ECU
Nissan	285563ZA0A	Memory Directly	OBP	Airbag ECU
Nissan	285563AD1A	Memory Directly	OBP	Airbag ECU
Nissan	98820EV50A	Memory Directly	OBP	Airbag ECU
Nissan	28556WL00A	Memory Directly	OBP	Airbag ECU
Nissan	98820JE50B	Memory Directly	OBP	Airbag ECU
Nissan	255560FJ0A	Memory Directly	OBP	Airbag ECU
Nissan	28556EE700	Memory Directly	OBP	Airbag ECU
Nissan	28556VJXXX	Memory Directly	OBP	Airbag ECU
Nissan	28556EW33E	Memory Directly	OBP	Airbag ECU
Nissan	988201BM1A	Memory Directly	OBP	Airbag ECU
Nissan	285563AD1B	Memory Directly	OBP	Airbag ECU
Nissan	98820JF40A	Memory Directly	OBP	Airbag ECU



<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Nissan	285561YP0A	Memory Directly	OBP	Airbag ECU
Nissan	988205Y605	Memory Directly	OBP	Airbag ECU
Nissan	988203DC0B	Memory Directly	OBP	Airbag ECU
Nissan	988201FC0A	Memory Directly	OBP	Airbag ECU
Nissan	98820EW40A	Memory Directly	OBP	Airbag ECU
Nissan	285563DN0B	Memory Directly	OBP	Airbag ECU
Nissan	988201NC1A	Memory Directly	OBP	Airbag ECU
Nissan	98820EJ80A	Memory Directly	OBP	Airbag ECU
Nissan	988208Y72B	Memory Directly	OBP	Airbag ECU
Nissan	28556VK10A(Oting)	Memory Directly	OBP	Airbag ECU
Nissan	28556VK10A(Paladin)	Memory Directly	OBP	Airbag ECU
Nissan	988203AA0A	Memory Directly	OBP	Airbag ECU
Nissan	98820ZE10A	Memory Directly	OBP	Airbag ECU
Nissan	98820ED600	Memory Directly	OBP	Airbag ECU
Opel	05490636	Soldering Contacts	K&CAN	Airbag ECU
Opel	330518650 5WK43471	Memory Directly	OBP	Airbag ECU
Opel	92099726	Soldering Contacts	K&CAN	Airbag ECU
Peugeot	550892700	Memory Directly	OBP	Airbag ECU
Peugeot	550892900	Memory Directly	OBP	Airbag ECU
Peugeot	600237000	Memory Directly	OBP	Airbag ECU
Peugeot	600237100	Memory Directly	OBP	Airbag ECU
Peugeot	600237200	Memory Directly	OBP	Airbag ECU
Peugeot	600902800	Memory Directly	OBP	Airbag ECU
Peugeot	602327200	Memory Directly	OBP	Airbag ECU
Peugeot	602327300	Memory Directly	OBP	Airbag ECU
Peugeot	603602500	Memory Directly	OBP	Airbag ECU
Peugeot	9550109280	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Peugeot	9640722980	Memory Directly	OBP	Airbag ECU
Peugeot	9644903280	Memory Directly	OBP	Airbag ECU
Peugeot	9644903380	Memory Directly	OBP	Airbag ECU
Peugeot	9645840780	Memory Directly	OBP	Airbag ECU
Peugeot	9648832180	Soldering Contacts	ICP	Airbag ECU
Peugeot	9650109280	Memory Directly	OBP	Airbag ECU
Peugeot	9650109480	Memory Directly	OBP	Airbag ECU
Peugeot	9652275880	Memory Directly	OBP	Airbag ECU
Peugeot	9652712180	Memory Directly	OBP	Airbag ECU
Peugeot	9653493380	Memory Directly	OBP	Airbag ECU
Peugeot	9654491180	Memory Directly	OBP	Airbag ECU
Peugeot	9654491280	Memory Directly	OBP	Airbag ECU
Peugeot	9660349980	Memory Directly	OBP	Airbag ECU
Peugeot	9661872980	Memory Directly	OBP	Airbag ECU
Peugeot	602327300	Memory Directly	OBP	Airbag ECU
Peugeot	9665355680	Memory Directly	OBP	Airbag ECU
Peugeot	9673787080	Memory Directly	OBP	Airbag ECU
Peugeot	9673786980	Memory Directly	OBP	Airbag ECU
Peugeot	9802958480	Memory Directly	OBP	Airbag ECU
Renault	8200018830B	Memory Directly	OBP	Airbag ECU
Renault	8200018835A	Memory Directly	OBP	Airbag ECU
Renault	8200027784B	Memory Directly	OBP	Airbag ECU
Renault	8200058365D	Memory Directly	OBP	Airbag ECU
Renault	8200098401	Memory Directly	OBP	Airbag ECU
Renault	8200111667	Memory Directly	OBP	Airbag ECU
Renault	8200111671	Memory Directly	OBP	Airbag ECU
Renault	8200111672	Memory Directly	OBP	Airbag ECU

Manufacturer	Airbag ECU Type	Method	Adapter	Storage Location
Renault	8200117651	Memory Directly	OBP	Airbag ECU
Renault	8200117652	Memory Directly	OBP	Airbag ECU
Renault	8200138952	Memory Directly	OBP	Airbag ECU
Renault	8200148339	Memory Directly	OBP	Airbag ECU
Renault	8200154716	Memory Directly	OBP	Airbag ECU
Renault	8200272510	Memory Directly	OBP	Airbag ECU
Renault	8200307800	Memory Directly	OBP	Airbag ECU
Renault	8200314053	Memory Directly	OBP	Airbag ECU
Renault	8200354723	Memory Directly	OBP	Airbag ECU
Renault	8200381668	Memory Directly	OBP	Airbag ECU
Renault	8200411004	Memory Directly	OBP	Airbag ECU
Renault	8200481132	Memory Directly	OBP	Airbag ECU
SSangYong	86250-08040	Soldering Contacts	ICP	Airbag ECU
SSangYong	86250-09041	Memory Directly	OBP	Airbag ECU
Subaru	152300-6131	Memory Directly	OBP	Airbag ECU
Subaru	98221AG170	Memory Directly	OBP	Airbag ECU
Subaru	98221XA05A	Memory Directly	OBP	Airbag ECU
Subaru	TN150300-0900	Memory Directly	OBP	Airbag ECU
Subaru	150300-0940	Memory Directly	OBP	Airbag ECU
Subaru	98221SA140	Memory Directly	OBP	Airbag ECU
Subaru	98221SC030	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-56K00	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-56K02-000	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-59J70-000	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-76JD0	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-77J00	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-77J02-000	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
SUZUKI	3891-77J10-000	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-56K12-000	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-57MB0	Memory Directly	OBP	Airbag ECU
SUZUKI	38910-77J01-000	Memory Directly	OBP	Airbag ECU
Toyota	89170-02160	Memory Directly	OBP	Airbag ECU
Toyota	89170-02250	Memory Directly	OBP	Airbag ECU
Toyota	89170-02290	Memory Directly	OBP	Airbag ECU
Toyota	89170-02410	Memory Directly	OBP	Airbag ECU
Toyota	89170-02430	Memory Directly	OBP	Airbag ECU
Toyota	89170-02700	Memory Directly	OBP	Airbag ECU
Toyota	89170-02760	Memory Directly	OBP	Airbag ECU
Toyota	89170-02770	Memory Directly	OBP	Airbag ECU
Toyota	89170-02A90	Memory Directly	OBP	Airbag ECU
Toyota	89170-05050	Memory Directly	OBP	Airbag ECU
Toyota	89170-05120	Memory Directly	OBP	Airbag ECU
Toyota	89170-06010	Memory Directly	OBP	Airbag ECU
Toyota	89170-06230	Memory Directly	OBP	Airbag ECU
Toyota	89170-06330	Memory Directly	OBP	Airbag ECU
Toyota	89170-06340	Memory Directly	OBP	Airbag ECU
Toyota	89170-08060	Memory Directly	OBP	Airbag ECU
Toyota	89170-0D080	Memory Directly	OBP	Airbag ECU
Toyota	89170-0D190	Memory Directly	OBP	Airbag ECU
Toyota	89170-0D360	Memory Directly	OBP	Airbag ECU
Toyota	89170-0D500	Memory Directly	OBP	Airbag ECU
Toyota	89170-0E010	Memory Directly	OBP	Airbag ECU
Toyota	89170-0N010	Memory Directly	OBP	Airbag ECU
Toyota	89170-0N020	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Toyota	89170-0P010	Memory Directly	OBP	Airbag ECU
Toyota	89170-12110	Memory Directly	OBP	Airbag ECU
Toyota	89170-12130	Memory Directly	OBP	Airbag ECU
Toyota	89170-12280	Memory Directly	OBP	Airbag ECU
Toyota	89170-12400	Memory Directly	OBP	Airbag ECU
Toyota	89170-12410	Memory Directly	OBP	Airbag ECU
Toyota	89170-13020	Memory Directly	OBP	Airbag ECU
Toyota	89170-26220	Memory Directly	OBP	Airbag ECU
Toyota	89170-28170	Memory Directly	OBP	Airbag ECU
Toyota	89170-28230	Memory Directly	OBP	Airbag ECU
Toyota	89170-30210	Memory Directly	OBP	Airbag ECU
Toyota	89170-30430	Memory Directly	OBP	Airbag ECU
Toyota	89170-33020	Memory Directly	OBP	Airbag ECU
Toyota	89170-33100	Memory Directly	OBP	Airbag ECU
Toyota	89170-33260	Memory Directly	OBP	Airbag ECU
Toyota	89170-33350	Memory Directly	OBP	Airbag ECU
Toyota	89170-33460	Memory Directly	OBP	Airbag ECU
Toyota	89170-33560	Memory Directly	OBP	Airbag ECU
Toyota	89170-42090	Memory Directly	OBP	Airbag ECU
Toyota	89170-47390	Memory Directly	OBP	Airbag ECU
Toyota	89170-48080	Memory Directly	OBP	Airbag ECU
Toyota	89170-50060	Memory Directly	OBP	Airbag ECU
Toyota	89170-50120	Memory Directly	OBP	Airbag ECU
Toyota	89170-52120	Memory Directly	OBP	Airbag ECU
Toyota	89170-52170	Memory Directly	OBP	Airbag ECU
Toyota	89170-52180 V1	Memory Directly	OBP	Airbag ECU
Toyota	89170-52180 V2	Memory Directly	OBP	Airbag ECU

<b>Manufacturer</b>	<b>Airbag ECU Type</b>	<b>Method</b>	<b>Adapter</b>	<b>Storage Location</b>
Toyota	89170-52480	Memory Directly	OBP	Airbag ECU
Toyota	89170-52C10	Memory Directly	OBP	Airbag ECU
Toyota	89170-52K70	Memory Directly	OBP	Airbag ECU
Toyota	89170-60050	Memory Directly	OBP	Airbag ECU
Toyota	89170-60051	Memory Directly	OBP	Airbag ECU
Toyota	89170-60090	Memory Directly	OBP	Airbag ECU
Toyota	89170-60110	Memory Directly	OBP	Airbag ECU
Toyota	89170-60130	Memory Directly	OBP	Airbag ECU
Toyota	89170-60200	Memory Directly	OBP	Airbag ECU
Toyota	89170-60390	Memory Directly	OBP	Airbag ECU
Toyota	89170-87Z02	Memory Directly	OBP	Airbag ECU
Toyota	Camry 2002	Memory Directly	OBP	Airbag ECU
Toyota	Camry 2002 2.4	Memory Directly	OBP	Airbag ECU
Toyota	89170-0R040	Memory Directly	OBP	Airbag ECU
Toyota	89170-0R030	Memory Directly	OBP	Airbag ECU
Toyota	89170-42640	Memory Directly	OBP	Airbag ECU
Toyota	89170-0P050	Memory Directly	OBP	Airbag ECU
Toyota	89170-0E090	Memory Directly	OBP	Airbag ECU
Toyota	89170-50170	Memory Directly	OBP	Airbag ECU
Toyota	89170-07200	Memory Directly	OBP	Airbag ECU
Toyota	89170-02F10	Memory Directly	OBP	Airbag ECU
Toyota	89170-0R041	Memory Directly	OBP	Airbag ECU
Toyota	89170-28280	Memory Directly	OBP	Airbag ECU
Toyota	89170-02190	Memory Directly	OBP	Airbag ECU
Toyota	89170-02760	Memory Directly	OBP	Airbag ECU
Toyota	89170-02A80	Memory Directly	OBP	Airbag ECU
Toyota	89170-0D400	Memory Directly	OBP	Airbag ECU

Manufacturer	Airbag ECU Type		Method	Adapter	Storage Location
Toyota	89170-0D650		Memory Directly	OBP	Airbag ECU
Toyota	89170-0D660		Memory Directly	OBP	Airbag ECU
Toyota	89170-02A80		Memory Directly	OBP	Airbag ECU
Volkswagen	Bora	6RD959655A	Memory Directly	OBP	Airbag ECU
Volkswagen	Bora	6RD959655B	Memory Directly	OBP	Airbag ECU
Volkswagen	Bora	6R0959655B	Memory Directly	OBP	Airbag ECU
Volkswagen	Lavida	6RD959655D	Memory Directly	OBP	Airbag ECU
Volkswagen	Lavida	6RD959655B	Memory Directly	OBP	Airbag ECU
Volkswagen	Lavida	6RD959655	Memory Directly	OBP	Airbag ECU
Volkswagen	Lavida	6RD959655A	Memory Directly	OBP	Airbag ECU
Volkswagen	Lavida	6RD959655C	Memory Directly	OBP	Airbag ECU
Volkswagen	Lavida	6R0959655B	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6Q0909601E	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6Q0909601F(Without side airbag)	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6RD959655D 2010	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6RD959655B 2010	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6RD959655	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6RD959655C	Memory Directly	OBP	Airbag ECU
Volkswagen	Polo	6Q0909601F(With side	Memory Directly	OBP	Airbag ECU
Volkswagen	VW2		Soldering Contacts	K&CAN	Airbag ECU
Volkswagen	VW3/VW5/VW51		Soldering Contacts	K&CAN	Airbag ECU
Volkswagen	VW3(Jetta)		Soldering Contacts	ICP	Airbag ECU
Volkswagen	VW52		Soldering Contacts	ICP	Airbag ECU
Volkswagen	VW61(1C0909605F)		Soldering Contacts	ICP	Airbag ECU

Manufacturer	Airbag ECU Type	Method	Adapter	Storage Location
Volkswagen	VW62(Touran)	Soldering Contacts	ICP	Airbag ECU
Volkswagen	VW8(Sagitar 1KO 909 605R)	Memory Directly	OBP	Airbag ECU
Volkswagen	VW8(Sagitar 1KO 909 605T)	Memory Directly	OBP	Airbag ECU
Samsung	39550-51520	Memory Directly	OBP	Airbag ECU
MG Rover	10001800(Roewe 550)	Memory Directly	OBP	Airbag ECU
MG Rover	YWC901161(Roewe 750)	Memory Directly	OBP	Airbag ECU
MG Rover	30010435-09	Memory Directly	OBP	Airbag ECU
MG Rover	10043844-05	Memory Directly	OBP	Airbag ECU
MG Rover	PN10100784-01(350)	Memory Directly	OBP	Airbag ECU
MG Rover	10008699(750)	Memory Directly	OBP	Airbag ECU
MG Rover	10041784(W5)	Memory Directly	OBP	Airbag ECU
MG Rover	400000092	Memory Directly	OBP	Airbag ECU
MG Rover	609909700	Memory Directly	OBP	Airbag ECU
MG Rover	50019354-06	Memory Directly	OBP	Airbag ECU
MG Rover	10008700(Roewe 750)	Memory Directly	OBP	Airbag ECU
Cadillac	5WY72990	Memory Directly	OBP	Airbag ECU
Luxgen	28556SU110-5WK43987C	Memory Directly	OBP	Airbag ECU

Note: Update To Ver. 1.8.1504.10

Date: 2015-4-28